
95 YARD SOUTH SECTION 118 CARS

CHICAGO TRANSIT AUTHORITY


Locations Of: Telephones ● Fire Alarm Boxes ● Fire Extinguishers ● Hand Stingers ● Tie Cables ● Intercoms ● Track Number . . .

NOT DRAWN TO SCALE



... Power Sectionalizing Switches • Car Storage Capacity • Types Of Track Switches • Track Number

NOT DRAWN TO SCALE



Exact Locations Of And Tracks Controlled By Power Sectionalizing Switches Shown On Adjacent Track Map

(A)

DISCONNECT SWITCHES

220 220 A B

LOOK WEST SWITCHES LOCATED ON POLE AT TRACK 3 SOUTH OF 96TH ST.

0

DISCONNECT SWITCHES

220 TO TRK 3

LOOK WEST SWITCHES LOCATED ON POLE WEST SIDE OF TRACK 1 SOUTH OF 96TH ST.

(E)

TRACK SWITCHES

TRK 1	TRK	TRK	TRK 4	TRK 5

LOOK EAST SWITCHES LOCATED ON POLE OUTSIDE NORTH END OF SHOP ON TRACK 13

(G)

TRACK SWITCHES

TRK	TRK	TRK	TRK	TRK 10
0	-	0	3	10

LOOK EAST SWITCHES LOCATED ON POLE OUTSIDE NORTH END OF SHOP ON TRACK 13

①

SECTIONALIZING SWITCHES



LOOK WEST SWITCHES LOCATED ON POLE WEST SIDE OF TRACK 1 SOUTH OF 96TH ST. (B)

DISCONNECT SWITCHES

230	230
Α	В

LOOK WEST SWITCHES LOCATED ON POLE EAST SIDE OF TRACK 1 SOUTH OF 96TH ST.

❿

DISCONNECT SWITCHES



LOOK WEST SWITCHES LOCATED ON POLE WEST SIDE OF TRACK 1 SOUTH OF 96TH ST.

(F)

TIE SWITCHES

230	230	
TO	TO	
220	220	

LOOK EAST SWITCHES LDCATED ON POLE OUTSIDE NORTH END OF SHOP ON TRACK 13

(H)

TRACK & SHOP SWITCHES

TRK	TRK	TRK	SHOP
11	12	13	FEED

LOOK EAST SWITCHES LOCATED ON POLE OUTSIDE NORTH END OF SHOP ON TRACK 13

①

SECTIONALIZING SWITCHES



LOOK WEST SWITCHES LOCATED ON POLE WEST SIDE OF TRACK I SOUTH OF 96TH ST.

95TH YARD SPECIAL NOTES

- The stop boards at the south end of the platform on the northbound track and under the bridge must be obeyed.
- 2. When moving a train in either direction under the bridge, the horn must be sounded.
- 3. One of the middle tracks (M1, M2, M3, or M4) must be clear to allow access to the yard and the shop.
- 4. The normal position of the spring and stay switches on tracks 2, 6, 7, 9, 10, and 13 is for operation in the facing direction over track 13.
- The normal position of the spring and stay switches on track 3 and track 5 is for operation in the facing direction over track 5.
- The normal position of the spring and stay switch on track 7 is for operation in the facing direction over track 7.
- 7. The normal position of the spring and stay switch on track 12 is for operation in the facing direction over track 12.
- 8. The power switches are powered electrically. In case of a power failure these switches become spring and return switches.
- 9. Trains cannot be operated into or out of the shop when the red aspect is displayed. Trains may be operated into or out of the shop when the green aspect is displayed. The indication of the green aspect is "Proceed, the shop door is clear of the train."
- The track number markers are also train clearance markers.

RULE 227. SPEED IN YARDS

- (a) The speed of trains within Yard Limits must not exceed six (6) miles per hour.
- (b) Yard Foremen, Switchmen and Motormen operating trains on any tracks within Yard Limits must use no more than one (1) point of power and be prepared to stop immediately.